

1 Insert blue tool under rear panel and twist.
Repeat until rear panel comes off.



2 Flip open lock for ribbon cable and unplug it.



3 Remove screw &
gear shift knob.

Use a T10 torx
screwdriver.



4 Mount new Gear Shift Knob with BMW screw.



Use T10 torx
screwdriver.

Adjust cable length as needed.

5 Insert cable and press down cable lock.



6 Place new rear panel in position, press tight.

Installation is complete.

